

Instructions for Maintenance and Cleaning of Small Transport Containers

Cleaning
If required following inspection clean all elements of Transport Stabilisation Systems with Ready-to-use Sprays or wipes
<ul style="list-style-type: none"> • Allow 5 minutes contact time • Ensure thoroughly dry before returning to use.

Small Va-Q-Tec Transport Box and Stabilisation System		
Container – Outer Textile Bag		
Outer	Cordura	Check the bag for damage and/or soiling <ul style="list-style-type: none"> • Material surfaces • Handles • Closing mechanism • Pouches / Pockets • Plastic 'shoe'
Container – Insulated Inner		
Outer	EPP (Expanded Polypropylene) and PP (Polypropylene)	The following must be checked in detail for visible damage such as holes or breaks <ul style="list-style-type: none"> • The outer wall of the container • The inner walls of the container
Inner and Lid	EPP (Expanded Polypropylene) and PP (Polypropylene)	The following must be checked in detail for visible damage such as holes or breaks <ul style="list-style-type: none"> • The outer wall of the lid • The inner walls of the lid • The top of the lid • The bottom of the lid • The lid lip